

Technical support

Document name:

Drying Resist™

Description:

Essential guide to drying Resist™ film.

Drying the resist

It is important to wipe of excess water off the resist once the washout process is finished. We sell inexpensive blotting towels for this purpose. Gently dab the excess water, taking care not to apply too much pressure. Another way is to use a rubber squeegee and wipe the excess water off.

Drying the resist can be done in a variety of ways.

- ProBlast's Premier Film Dryer is an excellent fast method and has convenient racking. Drying will take 5 – 8 minutes.
- Air-drying is an alternative way of drying your resist. Hang it up with pegs and let it air dry. This will take about 20 – 30 minutes

It is very important to make sure the resist is completely dry before you apply the resist.